

*******SILA AMBIL PERHATIAN*******

LANGKAH PERTAMA :

Taip di H/Phone tuan dengan *#0000# akan terkeluar kod phone tuan contohnya RAE-6.

LANGKAH DUA :

Di Fail PDF ini sila taip Ctrl + F untuk membuat carian.....e.g :

masukkan RAE-6 di kotak carian itu...maka terpaparlah model telefon, kod tel. dan operating system (OS) tel.

|

Model	CodeName	Cellular system	Hardware	Software (platform)
Alcatel One Touch 535	BH4	GSM 900/1800		
Nokia 10 TMF-4PP	NMT450i	DCT1 or DCT2	Nokia OS	
Nokia 11	NMT450i	DCT1 or DCT2	Nokia OS	
Nokia 100	THX-9L	DCT1 or DCT2	Nokia OS	
Nokia 150	THF-2P	NMT450 DCT1 or DCT2	Nokia OS	
Nokia 250	THF-51P	NMT450 DCT1 or DCT2	Nokia OS	
Nokia 252	NHA-3	DCT1 or DCT2		
Nokia 282	NHA-9	DCT1 or DCT2		
Nokia 350	THF-6P	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 440	THF-8P	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 450	THF-7P	NMT450 DCT1 or DCT2	Nokia OS	
Nokia 450SE/450VIP	THF-9	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 540	THF-11P/THF-7P	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 550	THF-10	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 610	TFE-4		Nokia OS	
Nokia 640	THF-13	NMT450i DCT3	Nokia OS	
Nokia 650	THF-12	NMT450i DCT3	Nokia OS	
Nokia 720	TMF-4SP	NMT450i DCT1 or DCT2	Nokia OS	
Nokia 810	TFE-4R		Nokia OS	

Nokia 880	NHE-1XB	GSM 900	DCT1 or DCT2	Nokia OS
Nokia 918	NHA-5		DCT1 or DCT2	
Nokia 1011	NHE-2		DCT1 or DCT2	Nokia OS
Nokia 1100	RH-18	GSM 900/1800	DCT4	Nokia OS
Nokia 1100a	RH-38		DCT4	Nokia OS
Nokia 1100b	RH-36		DCT4	Nokia OS
Nokia 1101	RH-75		DCT4	Nokia OS
Nokia 1110	RH-70		DCT4	Nokia OS
Nokia 1110i/1112	RH-93			
Nokia 1220	NKC-1			
Nokia 1260	NKW-1			
Nokia 1261	NKW-1C			
Nokia 1600	RH-64		DCT4	Nokia OS
Nokia 1610	NHE-5		DCT1 or DCT2	Nokia OS
Nokia 1611	NHE-5SX		DCT1 or DCT2	Nokia OS
Nokia 1630	NHE-5NA		DCT1 or DCT2	Nokia OS
Nokia 1631	NHE-5SA		DCT1 or DCT2	Nokia OS
Nokia 2010	NHE-3		DCT1 or DCT2	Nokia OS
Nokia 2100	NAM-2		DCT3	Nokia OS
Nokia 2110	NHE-1XN		DCT1 or DCT2	Nokia OS
Nokia 2110i	NHE-4	GSM 900	DCT1 or DCT2	Nokia OS
Nokia 2110i	NHE-4NX	GSM 900	DCT1 or DCT2	Nokia OS
Nokia 2110i	NHK-IEA	GSM 1800	DCT1 or DCT2	Nokia OS
Nokia 2120/2160	NHC-4NE		DCT1 or DCT2	Nokia OS
Nokia 2140	NHK-1XA		DCT1 or DCT2	Nokia OS
Nokia 2146 (Orange)	NHK-4RY	GSM 1800	DCT1 or DCT2	Nokia OS
Nokia 2148	NHK-1		DCT1 or DCT2	Nokia OS
Nokia 2148i	NHK-4		DCT1 or DCT2	Nokia OS
Nokia 2170	NHP-4		DCT1 or DCT2	Nokia OS
Nokia 2180	NHD-4X		DCT1 or DCT2	Nokia OS
Nokia 2190	NHB-3NB		DCT1 or DCT2	Nokia OS
Nokia 2220	RH-40 or RH-42			
Nokia 2260	RH-39 or RH-41			

Nokia 2270	RH-3P			
Nokia 2275	RH-3DNG			
Nokia 2280	RH-17			
Nokia 2285	RH-3			
Nokia 2300	RM-4	DCT4	Nokia OS	
Nokia 2300	RM-5	DCT4	Nokia OS	
Nokia 2310	RM-189			
Nokia 2600	RH-59	DCT4	Nokia OS	
Nokia 2600	RH-60	DCT4	Nokia OS	
Nokia 2610	RH-86			
Nokia 2650	RH-53	EGSM 900, GSM 1800		Nokia OS/S40 1st
Nokia 2651	RH-54			
Nokia 2652				
Nokia 3100/3120	RH-19	EGSM 900, GSM 1800/1900	DCT4	Nokia OS/S40 1st
Nokia 3100b/3120b	RH-50		DCT4	Nokia OS/S40 1st
Nokia 3105	RH-48			
Nokia 3108	RH-6			
Nokia 3110	NHE-8	GSM 900 DCT1 or DCT2		Nokia OS
Nokia 3200	RH-30	DCT4		Nokia OS/S40 1st
Nokia 3200b	RH-31	DCT4		Nokia OS/S40 1st
Nokia 3210	NSE-8/NSE-9	GSM 900/1800	DCT3	Nokia OS
Nokia 3220	RH-37	EGSM 900, GSM 1800/1900	DCT4	Nokia OS/S40 2nd
Nokia 3220b	RH-49	GSM 850, GSM 1800/1900	DCT4	Nokia OS/S40 2nd
Nokia 3230	RM-51	GSM 900/1800/1900	WD2	Symbian 7.0s/S60 2nd FP1
Nokia 3250	RM-38	GSM 900/1800/1900	BB5	Symbian 9.1/S60 3rd
Nokia 3285	NSD-6HX			
Nokia 3300	NEM-1	GSM 900/1800	DCT4	Nokia OS/S40 1st
Nokia 3300 USA	NEM-2		DCT4	Nokia OS/S40 1st
Nokia 3310/3315	NHM-5	GSM 900/1800	DCT3	Nokia OS
Nokia 3320	NPC-1			
Nokia 3330	NHM-6		DCT3	Nokia OS
Nokia 3350	NHM-9			
Nokia 3360	NPW-1			

Nokia 3390	NPB-1NB				
Nokia 3390 Gold	NPB-1RB				
Nokia 3395	NPB-1BB	DCT3	Nokia OS		
Nokia 3410	NHM-2	GSM 900/1800	DCT3	Nokia OS	
Nokia 3510	NHM-8	EGSM 900, GSM 1800	DCT4	Nokia OS	
Nokia 3510i/3530	RH-9	EGSM 900, GSM 1800	DCT4	Nokia OS/S40 1st	
Nokia 3520	RH-21				
Nokia 3560	RH-14				
Nokia 3570 or 5170i	NSD-1FW				
Nokia 3585	NPD-1FW				
Nokia 3589i	RH-44				
Nokia 3590	NPM-8				
Nokia 3595	NPM-10				
Nokia 3600	NHM-10				
Nokia 3610	NAM-1	DCT3	Nokia OS		
Nokia 3620	NHM-10X				
Nokia 3650	NHL-8	GSM 900/1800/1900	WD2	Symbian 6.1/S60 1st	
Nokia 3660	NHL-8X	GSM 900/1800/1900	WD2	Symbian 6.1/S60 1st	
Nokia 3810	NHE-9	DCT1 or DCT2	Nokia OS		
Nokia 5100	NPM-6/NPM-6U	EGSM 900, GSM 1800/1900	DCT4	Nokia OS/S40 1st	
Nokia 5100	NPM-6X	GSM 850, GSM 1800/1900	DCT4	Nokia OS/S40 1st	
Nokia 5110	NSE-1	GSM 900 DCT3	Nokia OS		
Nokia 5110i	NSE-2	GSM 900 DCT3	Nokia OS		
Nokia 5120	NSC-1NX	AMPS 800, TDMA 800	DCT3	Nokia OS	
Nokia 5130	NSK-1	GSM 1800	DCT3	Nokia OS	
Nokia 5140	NPL-5	GSM 850, GSM 1800/1900	DCT4	Nokia OS/S40 2nd	
Nokia 5140b	NPL-4	GSM 900/1800/1900	DCT4	Nokia OS/S40 2nd	
Nokia 5140i	RM-104	GSM 900/1800/1900	DCT4	Nokia OS/S40 2nd	
Nokia 5160/5165	NSW-1	AMPS 800, TDMA 1900, TDMA 800	DCT3	Nokia OS	
Nokia 5170	NSD-1F				
Nokia 5180	NSD-1G		Nokia OS		
Nokia 5185	NSD-1A				
Nokia 5185i	NSD-1AW				

Nokia 5190	NSB-1	DCT3	Nokia OS
Nokia 5210	NSM-5	EGSM 900, GSM 1800	DCT3 Nokia OS
Nokia 5300	RM-146	GSM 900/1800/1900	Nokia OS/S40 3rd FP1
Nokia 5300b	RM-147		Nokia OS/S40 3rd FP1
Nokia 5500	RM-86		
Nokia 5510	NPM-5	EGSM 900, GSM 1800	DCT3 Nokia OS
Nokia 6010	NPM-10X		
Nokia 6011	RTE-2RH		
Nokia 6015i or 6016i		RH-55	
Nokia 6020	RM-30	DCT4	Nokia OS/S40 2nd
Nokia 6020b	RM-31		Nokia OS/S40 2nd
Nokia 6021	RM-94		
Nokia 6030	RM-74		
Nokia 6050	NME-1		
Nokia 6060	RH-73		
Nokia 6070	RM-166		
Nokia 6080	NME-2		
Nokia 6081	NME-2E		
Nokia 6090	NME-3		
Nokia 6100	NPL-2	EGSM 900, GSM 1800/1900	Nokia OS
Nokia 6101/6102	RM-76		Nokia OS/S40 2nd
Nokia 6101b/6102b		RM-77	Nokia OS/S40 2nd
Nokia 6102i/6103b	RM-162		
Nokia 6103	RM-161		Nokia OS/S40 2nd
Nokia 6108	RH-4		
Nokia 6110	NSE-3	GSM 900 DCT3	Nokia OS
Nokia 6111	RM-82		Nokia OS/S40 3rd
Nokia 6120	NSC-3		
Nokia 6125	RM-178	BB5	Nokia OS/S40 3rd
Nokia 6126/6133b	RM-126		
Nokia 6130	NSK-3	GSM 1800	DCT3 Nokia OS
Nokia 6131	RM-115	BB5	Nokia OS/S40 3rd
Nokia 6136	RM-199		

Nokia 6150	NSM-1	GSM 900/1800	DCT3	Nokia OS
Nokia 6160/6162/6160m	NSW-3	AMPS 800, TDMA 1900, TDMA 800	DCT3	Nokia OS
Nokia 6170	RM-47			Nokia OS/S40 2nd
Nokia 6170b	RM-48			Nokia OS/S40 2nd
Nokia 6185/6188	NSD-3AX/NSD-3AY			
Nokia 6185i	NSD-3AW			
Nokia 6190	NSB-3		DCT3	Nokia OS
Nokia 6200	NPL-3			
Nokia 6210	NPE-3	EGSM 900, GSM 1800	DCT3	Nokia OS
Nokia 6220	RH-20	EGSM 900, GSM 1800/1900	DCT4	Nokia OS/S40 1st
Nokia 6225	RH-27			
Nokia 6230	RH-12	EGSM 900, GSM 1800/1900	TIKU	Nokia OS/S40 2nd
Nokia 6230b	RH-28	GSM 850, GSM 1800/1900	TIKU	Nokia OS/S40 2nd
Nokia 6230i	RM-72	EGSM 900, GSM 1800/1900	TIKU	Nokia OS/S40 2nd
Nokia 6233	RM-145		BB5	Nokia OS/S40 3rd FP1
Nokia 6234	RM-123		BB5	Nokia OS/S40 3rd FP1
Nokia 6250	NHM-3	EGSM 900, GSM 1800	DCT3	Nokia OS
Nokia 6260	RM-25		WD2	
Nokia 6270	RM-56		BB5	Nokia OS/S40 3rd
Nokia 6280	RM-78		BB5	Nokia OS/S40 3rd
Nokia 6282	RM-79			
Nokia 6310	NPE-4	EGSM 900, GSM 1800	DCT4	Nokia OS
Nokia 6310i	NPL-1	EGSM 900, GSM 1800/1900	DCT4	Nokia OS
Nokia 6325	RM-60			
Nokia 6340	NPM-2NX			
Nokia 6340i	RH-13			
Nokia 6360	NPW-2			
Nokia 6370	NHP-2FX			
Nokia 6385	NHP-2AX			
Nokia 6500/8310	NHM-7			
Nokia 6510	NPM-9		DCT4	
Nokia 6560	RH-25			
Nokia 6585	RH-34			

Nokia 6590	NSM-9				
Nokia 6600	NHL-10	WD2			
Nokia 6610/7210	NHL-4U/NHL-4		DCT4	Nokia OS	
Nokia 6610i	RM-37	GSM 900/1800/1900	DCT4	Nokia OS/S40 1st	
Nokia 6620	NHL-12				
Nokia 6630	RM-1	GSM 900/1800/1900, WCDMA 2100	BB5	Symbian 8.0a/S60 2nd FP2	
Nokia 6650	NHM-1	GSM 900/1800, WCDMA 2100	TIKU	Nokia OS/S40 1st	
Nokia 6670	RH-67	WD2			
Nokia 6670b	RH-68				
Nokia 6680	RM-36	BB5			
Nokia 6681	RM-57	BB5			
Nokia 6682	RM-58	GSM 850, GSM 1800/1900	BB5	Symbian 8.0a/S60 2nd FP2	
Nokia 6708	RM-139				
Nokia 6800	NHL-6	GSM 900/1800	DCT4	Nokia OS/S40 1st	
Nokia 6800 USA	NSB-9		DCT4	Nokia OS/S40 1st	
Nokia 6810	RM-2				
Nokia 6820	NHL-9	GSM 900/1800		Nokia OS/S40 1st	
Nokia 6820b	RH-26				
Nokia 6822a	RM-69			Nokia OS/S40 2nd	
Nokia 6822b	RM-68				
Nokia 7110	NSE-5	EGSM 900, GSM 1800	DCT3	Nokia OS	
Nokia 7160	NSW-5		DCT3	Nokia OS	
Nokia 7190	NSB-5		DCT3	Nokia OS	
Nokia 7200	RH-23	GSM 900/1800/1900			
Nokia 7200	RH-33				
Nokia 7250	NHL-4J	EGSM 900, GSM 1800/1900	DCT4	Nokia OS	
Nokia 7250i	NHL-4JX		DCT4	Nokia OS/S40 1st	
Nokia 7260	RM-17	GSM 900/1800/1900		Nokia OS/S40 2nd	
Nokia 7270	RM-8			Nokia OS/S40 2nd	
Nokia 7280	RM-14				
Nokia 7360	RM-127	GSM 900/1800/1900		Nokia OS/S40 2nd	
Nokia 7370	RM-70	BB5		Nokia OS/S40 3rd	
Nokia 7380	RM-111				

Nokia 7600	NMM-3	DCT4	Nokia OS/S40 1st
Nokia 7610	RH-51	GSM 900/1800/1900	WD2 Symbian 7.0s/S60 2nd FP1
Nokia 7610b	RH-52	WD2	Symbian 7.0s/S60 2nd FP1
Nokia 7650	NHL-2	EGSM 900, GSM 1800	WD2 Symbian 6.1/S60 1st
Nokia 7700	RAL-2		
Nokia 7710	RM-12	APE	
Nokia 8110/8110i	NHE-6	GSM 900 DCT1 or DCT2	Nokia OS
Nokia 8146/8148	NHK-6	GSM 1800	DCT1 or DCT2 Nokia OS
Nokia 8148i	NHK-6V	GSM 1800	DCT1 or DCT2 Nokia OS
Nokia 8210	NSM-3	EGSM 900, GSM 1800	DCT3 Nokia OS
Nokia 8250	NMS-3D	DCT3	Nokia OS
Nokia 8260	NSW-4		
Nokia 8265	NPW-3		
Nokia 8270	NSD-5FX		
Nokia 8280	RH-10		
Nokia 8290	NSB-7	DCT3	Nokia OS
Nokia 8390	NSB-8		
Nokia 8800	RM-13		
Nokia 8801	RM-33		
Nokia 8810	NSE-6	GSM 900 DCT3	Nokia OS
Nokia 8850	NSM-2	EGSM 900, GSM 1800	DCT3 Nokia OS
Nokia 8855	NSM-4		
Nokia 8860	NSW-6		
Nokia 8890	NSB-6		
Nokia 8910	NHM-4	DCT4	Nokia OS
Nokia 8910i	NHM-4NX	DCT4	Nokia OS/S40 1st
Nokia 9000	RAE-1	GSM 900 DCT1 or DCT2	GEOS 3.0
Nokia 9000i	RAE-4		
Nokia 9000il	GE-9		
Nokia 9110	RAE-2	DCT3	GEOS 3.0
Nokia 9210	RAE-3		
Nokia 9210i	RAE-5		
Nokia 9290	RAB-3		

Nokia 9300	RAE-6	APE	Symbian 7.0s/S80 2nd
Nokia 9300b	RA-4	APE	Symbian 7.0s/S80 2nd
Nokia 9300i	RA-8	APE	Symbian 7.0s/S80 2nd
Nokia 9500	RA-2	APE	Symbian 7.0s/S80 2nd
Nokia 9500b	RA-3	APE	Symbian 7.0s/S80 2nd
Nokia Card Phone 1.0	RPE-1		
Nokia Card Phone 2.0	RPM-1		
Nokia Cityman	CD60HP	NMT450	DCT1 or DCT2 Nokia OS
Nokia E50-1	RM-170		
Nokia E50-2	RM-171		
Nokia E60-1	RM-49	GSM 900/1800/1900, WCDMA 2100	BB5 Symbian 9.1/S60 3rd
Nokia E61-1	RM-89	BB5	Symbian 9.1/S60 3rd
Nokia E70-1	RM-10	BB5	Symbian 9.1/S60 3rd
Nokia E70-2	RM-24	BB5	Symbian 9.1/S60 3rd
Nokia Mobira	MD-95NB/ME-59NR	NMT450	DCT1 or DCT2 Nokia OS
Nokia Mobira CityMan 5000	NHE-1XA	GSM 900	DCT1 or DCT2 Nokia OS
Nokia N-Gage	NEM-4	EGSM 900, GSM 1800/1900	WD2 Symbian 6.1/S60 1st
Nokia N-Gage QDRH-29		EGSM 900, GSM 1800	WD2 Symbian 6.1/S60 1st
Nokia N-Gage QDa	RH-47	GSM 850, GSM 1900	WD2 Symbian 6.1/S60 1st
Nokia N70	RM-84	GSM 900/1800/1900, WCDMA 2100	BB5 Symbian 8.1a/S60 2nd FP3
Nokia N70 Chinese	RM-99	BB5	Symbian 8.1a/S60 2nd FP3
Nokia N71-1	RM-67	GSM 900/1800/1900, WCDMA 2100	BB5 Symbian 9.1/S60 3rd
Nokia N72	RM-180		
Nokia N80-1	RM-92	BB5	Symbian 9.1/S60 3rd
Nokia N80-3	RM-91	BB5	Symbian 9.1/S60 3rd
Nokia N90	RM-42	GSM 900/1800/1900, WCDMA 2100	BB5 Symbian 8.1a/S60 2nd FP3
Nokia N91-1	RM-43	BB5	Symbian 9.1/S60 3rd
Nokia N91-5 Chinese	RM-158	BB5	Symbian 9.1/S60 3rd
Nokia N92		BB5	Symbian 9.1/S60 3rd
Nokia N93	RM-55	BB5	Symbian 9.1/S60 3rd
Nokia Talkman	TMF-3SP	NMT450	DCT1 or DCT2 Nokia OS
Nokia Talkman 620	TMF-1P	NMT450	DCT1 or DCT2 Nokia OS
SE T68i	T68i		

SE T610 T610